
Coffee Table

Assembly Instructions - Please keep for future reference

1061030170A

1061030171A



Dimensions

Width - 39.8inch

Depth - 22 inch

Height - 17.3inch

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste.
 Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightend properly.


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

	T T T T T T T T T T T T T T T T T T T	
A	B (((()))	©
8*30mm Wooden Dowel x 28	7*39mm Cam Bolt x 20	Cam Lock x 20
	()	6
3.5*14mm Screw x 16	5*40mm Screw x 6	Protective Feet x 6
G	H	
Hinge x 4	Glass Shelf Clamp x 4	LED Mounting Bracket x 2
	&	•
LED lights kit x 1	Door Bumper x 2	Double Sided Tape x 1

Tools required



Phillips screwdriver (medium & large)

Ruler - Use this ruler to help correctly identify the screws


0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

The screws length is measured from the head to the point (30mm screw shown).

Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.



Adjusting Hinges


Hinge adjustment:


a: To move the door up or down, loosen screws shown and move door to suit


b: To move the door in or out, loosen screws shown and move door to suit.


Retighten screws


c: To move the door left or right, adjust screws shown.














Components - Panels

Please check you have all the panels listed below








2 (33.5 x 52.7 x 1.5cm) x 1



3 (33.5 x 52.7 x 1.5cm) x 1 4 (33.5 x 55.8 x 1.5cm) x 1





5 (91 x 7.5 x 1.5cm) x 2




6 (43x 7.5 x 1.5cm) x 2





7 (56 x 1014 x 1.5cm) x 1 8 (32.8 x 38.9 x 1.5cm) x 2








9 (59.5 x 52 x 0.4cm) x 1














7


Attach cam bolt (B) to part (5) with a screwdriver.

part (5, 6) to lock it.











Attach cam bolt (B) to top panel (1) with a screwdriver.




Install 4 AA batteries (Not included) into the battery box, then use double sided tape to attach the battery box to the top panel.



Attach top panel (1) to part (2, 3, 4), then insert and secure cam lock (C) to part (2, 3, 4) to lock it.


Step 11






Attach glass shelf clamp (H) to part (3, 4).

Step 12



Slide part (9) through glass shelf clamp (H), and tighten the clamp.





Use screw (D) to secure hinge (G) to part (2) with a screwdriver, and then attach door bumper (K) to part (3). You may refer to page 3 about how to adjust hinge.

