
Sideboard

Assembly Instructions - Please keep for future reference

1061120217B-A 1061120218B-B

1061120219B-A 1061120220B-B

1061120221B-A 1061120222B-B



Dimensions

Width - 42inch

Depth - 15.5inch

Height - 72inch

It takes 2 people roughly 2-3 hours to assemble the whole piece. A power drill is highly recommended.

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste.
 Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING In order to help prevent overturning – please follow these instructions


To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


please note that only the anti tip strap is provided.

You will need to provide wall plugs and screws applicable for your wall type


Part List: A



Part List: A



Part List: B




Components - Fittings

Please check you have all the panels listed below

Note: The quantitie below are the correcet amount to complete the assembly. In some cases more fittings may be supplied than are required.

Male Camlock x 86 Female Camlock x 86 Dowel (8x30) x 64 The state of the state o	A CO	B	G
Orawer slider 12" X 3 3.5*12mm Screw x 34 3.5*12mm Screw x 34 Protective Feet x 4 Protective Feet x 4 Protective Feet x 4 4*30mm Screw x 12 A*30mm Screw x 12 A*30mm Screw x 12 A*45mm Screw x 16	/lale Camlock x 86	Female Camlock x 86	Dowel (8x30) x 64
3*17mm Screw x 32 Plasticwedge x 28 Protective Feet x 4 Protective Feet x 4 4*30mm Screw x 12 5*45mm Screw x 16 W Handle & Fixings x 2 Handle & Fixings x 2 Handle & Fixings x 3 Pulley x 4 S Plate x 4 Adjustable Foot x 1 U Cup holder x 1 Light Strip x 1 Shelf Support Pin x 20			
3*17mm Screw x 32 Plasticwedge x 28 Protective Feet x 4 4*30mm Screw x 12 5*45mm Screw x 16 At a somm Screw x 12 At a somm Screw x 12 At a somm Screw x 12 Adjustable Foot x 1 Cup holder x 1 Adjustable Foot x 1 Cup holder x 1 Adjustable Foot x 1 Adjustable Foot x 1 Adjustable Foot x 1	Drawer slider 12" X 3	x 3	3.5*12mm Screw x 34
Door Hinge x 4 4*30mm Screw x 12 5*45mm Screw x 16 W Handle & Fixings x 2 Handle & Fixings x 2 Handle & Fixings x 3 Pulley x 4 W Cup holder x 1 Light Strip x 1 Shelf Support Pin x 20		H	•
Door Hinge x 4 4*30mm Screw x 12 5*45mm Screw x 16 W Handle & Fixings x 2 Handle & Fixings x 2 Handle & Fixings x 3 Pulley x 4 Shelf Support Pin x 20 Powel (8x50) x 8	3*17mm Screw x 32	Plasticwedge x 28	Protective Feet x 4
Handle & Fixings x 2 Handle & Fixings x 2 Handle & Fixings x 2 Handle & Fixings x 3 Pulley x 4 Pulley x 4 Adjustable Foot x 1 Light Strip x 1 Shelf Support Pin x 20			
Handle & Fixings x 2 Handle & Fixings x 2 Handle & Fixings x 3 Pulley x 4 Pulley x 4 Adjustable Foot x 1 Cup holder x 1 Light Strip x 1 Shelf Support Pin x 20	Door Hinge x 4	4*30mm Screw x 12	5*45mm Screw x 16
P 6*40mm Screw x 8 Magnet Touch x 2 Pulley x 4 Pulley x 4 Adjustable Foot x 1 Cup holder x 1 Light Strip x 1 Shelf Support Pin x 20	M 🕵	O C	o
6*40mm Screw x 8 Magnet Touch x 2 Pulley x 4 Pulley x 4 Adjustable Foot x 1 U Cup holder x 1 Light Strip x 1 Shelf Support Pin x 20	Handle & Fixings x 2	Handle & Fixings x 2	Handle & Fixings x 3
Plate x 4 Adjustable Foot x 1 Cup holder x 1 Light Strip x 1 Shelf Support Pin x 20	P	0	R S
Plate x 4 4*14mm Screw x 42 Adjustable Foot x 1 Cup holder x 1 Light Strip x 1 Shelf Support Pin x 20	6*40mm Screw x 8	Magnet Touch x 2	Pulley x 4
Cup holder x 1 Light Strip x 1 Shelf Support Pin x 20	S		0
Cup holder x 1 Light Strip x 1 Shelf Support Pin x 20	Plate x 4	4*14mm Screw x 42	Adjustable Foot x 1
Powel (8v50) v 8	V	W	× D
Dowel (8v50) v 8	Cup holder x 1	Light Strip x 1	Shelf Support Pin x 20
Dowel (8v50) v 8	V	3	61 <====(3)
Wall Fixing Pack x 2 3*12mm Screw x 4	Dowel (8x50) x 8	Wall Fixing Pack x 2	3*12mm Screw x 4



Phillips screwdriver (medium & large)

Ruler - Use this ruler to help correctly identify the screws


0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170 $\frac{1}{1000}$

The screws length is measured from the head to the point (30mm screw shown).

Using Camlocks


Step 1

Connect the male camlock as diected in the assembly instructions using a scewdriver.



Step 2

Push the male camlock into the entry hole.



Step 3

Insert the femle camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4


Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.


The joint is now secure.





Step 1





Step 2















Step 5






Step 6







Step 7





Step 8






















Step 19










Step 20











Step 22














































Step 51 B (Pr B x 4 ₀ 32 B 31 35 B 17 **FRONT** Step 52 B 35 B B **B BACK B**

32


Step 53











Step 54

















Step 61







Step 63








Step 64




Attention:


1.Align the slide runners on the drawer with the unit and push it carefully inside until it stops.

If the drawer does not go in smoothly please take it out and repeat the step.






Step 67



Attach bottom of doors to the sliding slot then close the doors to the sliding track. Slightly uplift the doors and hook pulley to the sliding track.




Step 69







ATTENTION:

For safety and stability, we suggest you have to secure the anti tip accessories to the wall to prevent tipping, injury, and property damage.





Step 70



A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.



Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for **supporting your unit. Consult a qualified tradesperson if you** are unsure.


Hints:

- 1: General rule: Always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 " Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.3 "Cavity Fixing" wall plug



For use with plasterboard partitions or hollow wooden doors.


No.4 " Cavity Fixing – Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.


Safety: always check the fitting and location to ensure your safety in and around the home.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 " Shield Anchor" wall plug – heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.

Care & Maintenance

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.