
TV Stand

Assembly Instructions - Please keep for future reference



Dimensions

Width - 70inch Depth - 14.9inch Height - 31.2inch

Any question please feel free to contact us: support@amer-life.com TEL:(901) 347-2181 We will provide further assistance within 24 hours.

Important – Please read these instructions fully before starting assembly

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners. • From time to time check that there are no loose screws on this unit.

 This product should not be discarded with household waste.
Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts • Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING In order to help prevent overturning – please follow these instructions


To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable) Do not allow children to climb or hang on the furniture Do not open more than one drawer at a time Do not place heavy items in the top drawers Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

please note that only the anti tip strap is provided. You will need to provide wall plugs and screws applicable for your wall type

Components - Panels


Please check you have all the panels listed below



2

Components - Panels

Please check you have all the panels listed below



33 (300X115X12mm)X2

34 (300X115X12mm)X2

35 (281X115X12mm)X2

36 (291X297X2.7mm)X2

Components - Fittings

Please check you have all the hardware listed below

Note: The quantitie below are the correcet amount to complete the assembly. In some cases more fittings may be supplied than are required.

A BIL M	B	G S
Male Camlock x 79	Female Camlock x 79	Dowel x 56
	6 Shananana	G Bar
Drawer slider 12"x 2	5*45mm Screw x 8	3*12mm Screw x 24
G gamma		0
4*30mm Screw x 16	Back Panel Stiffener x 8	Door Hinge x 4
J Sum		0 0
3.5*14mm Screw x 24	x 6	Shelf Support Pin x 8
		0 ~
6*20mm Screw x 12	6*12mm Screw x 12	Handle & Fixings x 4
0	Q P	
Wall Fixing Pack x 2	Protective Feet x 14	

Tools required


Phillips screwdriver (medium & large)


Ruler - Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170


The screws length is measured from the head to the point (30mm screw shown).


Using Camlocks







6








8



































































Step 50


Congratulation! You've made to the last step! But don't be too thrilled yet, put on the drawer can be frustrating if you do it wrong. So, take your time and follow the steps below.




1.Make sure that you have right and left drawers sorted out first, because the drawer panel may cover the side if the right drawer is on the left side, vise versa.




2.Please ensure that you have matched the wheels on BOTH sides of the drawer with the wheels on rails installed BEFORE push in the drawer.





3.If the following occurs, redo the first two steps.

32



Step 53

The unit is floor standing, but it is recommended that the unit is secured to the wall.

1. Move the unit into desired position.

2. Mark the wall with a suitable scribe the position of the fixing holes.




Warning: Before driling,check wall for hidden pipes and cables.

3. Drill holes and insert 2 x wall plug

4. Attach 2 x Wall Straps to to the top of the unit using 2 x Washers and 2 x Screws


5. Secure the straps to the wall using 2 x Washers and 2 x Screws

Note: To hide the straps behind the unit, drill the holes lower than the top of the unit




Assembly is complete.

A Guide to Wall Mounting & Fixings





No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case.For light loads,general purpose wall plugs can be used.

No.2 "Plasterboard"





For use when attaching light loads onto plasterboard partitions.



No.3 "Cavity Fixing" wall plug

For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing - Heavy Duty"

For use when fitting or supporting


heavy loads such as shelving, wall

cabinets and coat racks.

5


wall plug

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.



Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.