


Outdoor wooden Storage Shed

Assembly Instruction - Please keep properly for future reference.

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.



CONTACT US

- **Email: service@grandtunnel.com**

In order to receive assistance more quickly, please provide




















THE FOLLOWING INFORMATION:

- Order number
- Purchase platform
- Purchase date
- Detailed description of the issue along with photos (if applicable)










EN

Important – Please read these instructions carefully before starting the installation.

Parts List

1  687X528MM X1	2  687X528MM X1	3  950X570MM X1	4  950X570MM X1	5  620X570MM X1
6  620X570MM X1	7  687X528MM X1	8  687X528MM X1	9  691X422MM X1	10  691X422MM X1
11  576X628MM X1	12  800X628MM X1	13  876X280MM X1	14  1052X526MM X1	15  1160X625MM X1
16  527X422MM X2	17  529X422MM X1	18  1066X34MM X1	19  300X30MM X2	20  1066X34MM X1

Parts List

Parts List					
21	22	23	24		
					
1052X18MM	1052X65MM	511X65MM	150X18MM		
X1	X1	X2	X2		
A	B	C	D	E	F
					
3.5*55	3.5*40	3.5*35	3.5*30	3.5*20	3*18
X6	X21	X16	X30	X12	X16
G	H	I	J	K	L
					
X8	X1	X1	X2	X1	Ø6*20
X15					

CUSTOMER SERVICE GUIDE

Thank you for choosing our product! We are committed to providing you with excellent service. If you find any missing parts, damaged packaging, or product damage after receiving all packages, please follow the steps below to quickly contact our customer service team. We will do our best to resolve your issue.

1. Missing Parts

Verify Parts:

1. Refer to the “Parts List” in the manual to verify the name, specifications, and quantity of the missing parts.
2. Take a clear photo of the parts list and mark the missing parts with detailed information, e.g., “Missing 5 pieces of M6x30mm screws.”

Contact Us:

· By Email:

Send an email to service@grandtunnel.com, with the subject line “Missing Parts Issue.” Include the following in the email:

- A description of the missing parts and a photo of the parts list.
- Order details (order number, purchase platform, purchase date).

2. Product or Packaging Damage

If it affects normal use:

Steps:

1. Take clear photos or videos showing the damaged parts and the extent of the damage (multi-angle shots are recommended).
2. Email the photos/videos along with other details to service@grandtunnel.com, with the subject line “Product Damage Issue.”

Resolution:

After verification, we will arrange for a replacement part, product exchange, or refund as quickly as possible.

If it does not affect normal use:

Steps:

1. Contact our customer service team (by email: service@grandtunnel.com).
2. Provide a description of the damage and include relevant photos or videos.

Resolution:

We will provide repair guidance or an appropriate compensation plan based on the specific situation.

Contact Us:






- Customer Service Email: service@grandtunnel.com

Helpful Tips


To process your issue efficiently, please prepare the following information:

- Order details (order number, purchase platform, purchase date).
- Clear photos or videos.
- We are committed to providing quick and professional solutions, no matter the size of the issue, to ensure your satisfaction.

Thank you for your trust and support! We hope you enjoy using our product!


1	 1 X1	 2 X1	 7 X1	 8 X1	 21 X1	 22 X1
---	---	---	---	--	--	--

Insert the wooden dowels (L) into the bottom ends of panel (1) and panel (2).
 At the same time, use screws (C) to attach panel (21) to panel (1) and panel (2).
 Use screws (D) to secure panel (22) to panel (1), panel (2), panel (7), and panel (8).
 Use screws (F) to fasten the metal plate (I) to the top ends of panel (7) and panel (8).




CX4  3.5*35	DX8  3.5*30	FX2  3*18	IX1 	LX2  M6*20
--	--	--	--	---


2



3 X1



4 X1




Use screws (B) to attach panel (3) to panel (1), and at the same time use screws (B) to attach panel (4) to panel (2).

BX8




3.5*40

3



18 X1




Use screws (B) to secure panel (18) to panel (3) and panel (4).
(Ensure that the dowel hole is positioned on the side of panel (3).)

BX2




3.5*40

4




14 X1



14

Insert panel (14).


5



9 X1



24 X1



Insert the wooden dowels (L) into both ends of panel (9).
Insert the wooden dowels (L) into the left side to connect with panel (24),
and at the same time use screws (C) to fix panel (24) onto panel (9).

CX2




3.5*35

LX3



M6*20

6



Use screws (B) to attach panel (9) to panel (3), and at the same time use screws (A) to reinforce the connection between panel (9) and panel (18).

AX1




3.5*55

BX3




3.5*40

7




16 X1




Insert the shelf supports (G) into panel (9) and panel (1) at the same time.
Then place panel (16) in position.


GX4




8



5 X1



23 X1




Use screws (D) to attach panel (23) to panel (5) and panel (3).

DX6



3.5*30

9




Use screws (B) to secure panel (5) to panel (7).

BX2




3.5*40

10



17 X1




Connect panel (17) using the wooden dowels (L), and at the same time secure it to panel (7) with screws (D).

DX2




3.5*30

LX2



Ø6*20


11



10 X1




24 X1



24

10

C




a. Connect panel (24) using the wooden dowels (L), and secure it to panel (10) with screws (C).

CX2




3.5*35

LX1




Ø6*20

12



13 X1




Attach accessory (J) to panel (13) using screws (E).

EX4




JX2



3.5*20

13



Attach accessory (J) to panel (10) using screws (E).



EX8



3.5*20

14

Connect panel (10) using the wooden dowels (L) and secure it to panel (17) with screws (C).
At the same time, use screws (B) to fasten panel (5) to panel (10).



BX3




3.5*40

CX2




3.5*35

LX2




Ø6*20


15



6 X1



23 X1



Use screws (D) to secure panel (23) to panel (6) and panel (4).


DX6



3.5*30

16

Use screws (B) to attach panel (6) to panel (8).
Insert the shelf supports (G) into panel (10) and panel (7) at the same time,
and use screws (A) to secure panel (10) to panel (9).



AX2



3.5*55

BX2




3.5*40



GX4



17




16 X1




Insert panel (16).

LX1




Ø6*20

18



20 X1




Use screws (A) to secure panel (20) to panel (5), panel (6), and panel (10).

AX3




3.5*55

19




11 X1



12 X1



19 X2




Use screws (D) to attach panel (19) to panel (11) and panel (12).

DX8




3.5*30





Use screws (F) to secure panel (11) and panel (12) to panel (6) and panel (4).

FX12




3*18

21




Attach handle (H) to panel (11).

HX1




22




Insert the wooden dowels (L) into the top ends of panel (5) and panel (6).

LX2




Ø6*20

23



15 X1



Secure panel (15) with screws (C), and at the same time reinforce it from panel (20) using screws (B).

BX1



3.5*40

CX6



3.5*35




Attach accessory (K) using screws (F).

FX2



KX1



3*18

| Outdoor wooden Storage Shed

SKU:
BI3051-1A1A0

V1.0