


Cabinet

Assembly Instruction - Please keep properly for future reference.

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.



Arrive in 2 separate boxes and may not be part of the same shipment. Please install the product after receiving all the packages.

32x16 FT

CONTACT US

- **Email: info@grandtunnel.com**

In order to receive assistance more quickly, please provide

THE FOLLOWING INFORMATION:

- Order number
- Purchase platform
- Purchase date
- Detailed description of the issue along with photos (if applicable)

EN

Important – Please read these instructions carefully before starting the installation.

Safety and Care Advice

Thank you for choosing this product! To ensure safe use and long-term maintenance, please read this manual carefully and keep it for future reference.

Important Notes:

This product is designed for indoor use only and should not be used for commercial or outdoor purposes without authorization.

Children under the age of 14 should not participate in the assembly process.

Important - Please read these instructions fully before starting assembly

1. Preparation Before Assembly

Check Components and Tools:

Refer to the provided parts list to ensure all components and fittings are included. If any parts are missing or damaged, please contact customer service immediately.

Required Tools:

Prepare a Phillips screwdriver, a spirit level, a rubber mallet, and expansion bolts or screws suitable for your wall type (not included).

Workspace:

Assemble the product on a flat, soft surface (e.g., carpet) to avoid scratching the furniture.

Ensure the workspace is spacious enough to lay out all components and facilitate assembly.

Safety Precautions:

Keep children and pets away from the assembly area to prevent accidental injuries or swallowing of small parts.

Assembly by two people is recommended to improve efficiency and ensure safety.

2. Assembly Instructions

Initial Fixing:

Assemble the components in the order specified in the manual. Do not skip any steps.

Tighten screws and connectors loosely at first to allow for adjustments later.

Alignment Check:

Before fully tightening screws, ensure all grooves and holes are properly aligned to prevent incorrect assembly.

Wall Mounting (if applicable):

Use the included anti-topple device to secure the furniture to the wall. If suitable wall-mounting fittings are not provided, purchase appropriate expansion bolts and screws for your wall type.

Follow the wall-mounting guidelines to prevent tipping hazards.

3. Post-Assembly Checks

Verify that all parts are securely installed and screws are fully tightened.

Ensure the anti-topple device is properly installed.

Once the furniture is in its final position, use a spirit level to confirm it is level.

Usage Instructions

1. Safety Tips for Use

Prevent Tipping:

Always use the included anti-topple device to secure the furniture and prevent accidents.
Check the stability of the anti-topple device regularly.

Weight Distribution:

Place heavy items in the lower drawers or shelves to improve stability.
Avoid placing heavy objects on top of the furniture unless it is designed for such use.

Child Safety:

Do not allow children to climb, sit, or hang on the furniture.
Keep small parts and sharp objects stored inside drawers or cupboards, out of childrens reach.

2. Special Features (if applicable):

Lighting System:

Follow the instructions to correctly install electrical components, ensuring wires are not exposed.

If the LED strip or switch needs replacement, consult a professional.

Maintenance Instructions

1. Cleaning and Care

Wipe the surface with a slightly damp soft cloth and mild detergent. Avoid using bleach, solvents, or abrasive cleaners.

Regularly clean underneath and behind the furniture to prevent dust accumulation.

2. Regular Checks

Inspect screws and fittings regularly to ensure they are not loose, and tighten them if necessary.

Check the anti-topple device to ensure it is securely connected, and adjust immediately if any looseness is detected.

3. Preventing Environmental Damage

Avoid placing the furniture in damp areas to prevent material deformation or structural damage.

Protect the furniture from prolonged exposure to direct sunlight to prevent discoloration or surface aging.

4. Product Disposal

This product should not be disposed of as household waste. Please take the furniture to an authorized recycling facility in accordance with local regulations.

For products containing electrical components, ensure proper recycling as per the European Union Waste Electrical and Electronic Equipment Directive (WEEE).

Safety Warnings

1. Anti-Tip Warning

To prevent serious injury or death caused by furniture tipping over:

- A. Always use the included anti-tip device or other suitable wall-mounting hardware to securely anchor the furniture to the wall.
- B. Do not allow children to climb, hang, or play on the furniture.
- C. Avoid placing heavy items on the top drawer or the top surface of the furniture.

2. Installation Warnings

- Follow the assembly steps as outlined in the manual.
- Do not use high-torque power tools to avoid damaging screws or fittings.
- Do not move the furniture or place heavy items on it until assembly is fully completed.

3. Child Safety

- This product is not a toy. Keep all small parts and packaging materials out of reach of children.
- Using the anti-tip device is essential to ensure child safety.

4. Electrical Safety (If Applicable)

- Before using the product, ensure all electrical components are properly connected.
- Do not attempt to disassemble or modify the electrical parts. For replacements, consult a qualified electrician.

Customer Care

If you encounter any of the following issues, please contact our customer service team **promptly**:

- Missing or damaged parts.
- Questions during assembly.
- Issues related to product use or maintenance.

To assist us in resolving your concerns quickly, please provide the following information:

- Order number.
- Purchase platform.
- Purchase date.
- Detailed description of the issue and photos (if applicable).

Customer Service Contact Information:

- Email: info@grandtunnel.com

Compliance with European Market Regulations

• This manual complies with the General Product Safety Directive (GPSD) and relevant regulations for furniture product instructions in the UK (BS 14749), Germany, France, Spain, and Italy.

• All warnings and maintenance guidance provided are intended to ensure user safety and prolong the product's lifespan.

Thank you for your support and trust. Enjoy your product!

CUSTOMER SERVICE GUIDE

Thank you for choosing our product! We are committed to providing you with excellent service. If you find any missing parts, damaged packaging, or product damage after receiving all packages, please follow the steps below to quickly contact our customer service team. We will do our best to resolve your issue.

1. Missing Parts

Verify Parts:

1. Refer to the “ Parts List” in the manual to verify the name, specifications, and quantity of the missing parts.
2. Take a clear photo of the parts list and mark the missing parts with detailed information, e.g., “ Missing 5 pieces of M6×30mm screws.”

Contact Us:

. By Email:

Send an email to info@grandtunnel.com , with the subject line “ Missing Parts Issue.” Include the following in the email:

- . A description of the missing parts and a photo of the parts list.
- . Order details (order number, purchase platform, purchase date).

2. Product or Packaging Damage

If it affects normal use:

Steps:

1. Take clear photos or videos showing the damaged parts and the extent of the damage (multi-angle shots are recommended).
2. Email the photos/videos along with order details to info@grandtunnel.com , with the subject line “ Product Damage Issue.”

Resolution:

After verification, we will arrange for a replacement part, product exchange, or refund as quickly as possible.

If it does not affect normal use:

Steps:

1. Contact our customer service team (by email: info@grandtunnel.com).
2. Provide a description of the damage and include relevant photos or videos.

Resolution:

We will provide repair guidance or an appropriate compensation plan based on the specific situation.

Contact Us

- . Customer Service Email: info@grandtunnel.com

Helpful Tips

To process your issue efficiently, please prepare the following information:

- . Order details (order number, purchase platform, purchase date).
- . Clear photos or videos.
- . We are committed to providing quick and professional solutions, no matter the size of the issue, to ensure your satisfaction.

Thank you for your trust and support! We hope you enjoy using our product!

A Guide to Wall Mounting & Fixings

Important note:



Before Drilling: Always check for hidden wires or pipes in the wall.

Important Notes



Wall Plugs: If plastic wall plugs are supplied, they are only suitable for masonry walls.
For other wall types, consult a qualified tradesperson.
Installer Responsibility: Using incorrect fixings may result in product failure.


Hints for Safe and Secure Fixing

1. **Screw & Wall Plug Size:** Use a larger size if unsure.
2. **Drill Bit Selection:** Match the drill bit size to the wall plug.
3. **Drill Position:** Drill horizontally and avoid enlarging the hole.
4. **Care for Fragile Walls:** Insert wall plugs carefully in tiles or thin walls to prevent cracks.
5. **Tight Fit:** Ensure wall plugs fit snugly into drilled holes.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




General Purpose Wall Plug: For brick, concrete, and aerated blocks. Not suitable for heavy loads.

No.3 "Cavity Fixing" wall plug




Cavity Fixing Wall Plug: For hollow wooden doors or partitions.

No.5 "Hammer Fixing" wall plug




Hammer Fixing Plug: For walls stuck with plasterboard; ensure it anchors securely.

No.2 "Plasterboard" wall plug




Plasterboard Wall Plug: For light loads on plasterboard partitions.

No.4 "Cavity Fixing – Heavy Duty" wall plug



Heavy-Duty Cavity Fixing : For heavy loads like wall cabinets and shelves

No.6 "Shield Anchor" wall plug – heavy loads



Shield Anchor Wall Plug: For very heavy loads like TV brackets or speakers



Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.


Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.

. Regular Checks: Inspect fittings to ensure screws and wall plugs remain secure.. **Safety Reminder:** Always use appropriate fixings and regularly verify stability.

Using Camlocks


Step 1

- . Attach the Male Camlock
- . Insert the male camlock into the designated hole on the panel as shown in the instructions.
- . Secure it firmly using a screwdriver, ensuring it is tightly fitted
- .




Step 2

- . Insert the Male Camlock into the Entry Hole
- . Push the panel with the male camlock into the corresponding entry hole of the other panel.
- . Ensure the panels are aligned correctly to avoid damage during installation.




Step 3

- . Install the Female Camlock
- . Insert the female camlock into the pre-drilled hole on the receiving panel.
- . Ensure the arrow on the top of the camlock points towards the entry hole for the male camlock.



Step 4

- . Tighten the Female Camlock
- . Using a screwdriver, turn the female camlock clockwise until it locks the male camlock in place.
- . You should feel a click or resistance once the camlock is fully secured.




Note:

- . Do not overtighten to prevent damage to the camlock or the panel.. Ensure all camlocks are installed firmly before proceeding to the next assembly step.

Tips for Best Results:

- . Use a manual screwdriver to prevent overtightening.
- . Double-check alignment of the panels before tightening the camlocks to avoid misalignment.
- . If a camlock feels loose, disassemble and check for proper positioning before re-securing.

Assembly Instructions



Component Identification

Arrange the parts and hardware according to the exploded diagram to ensure you can easily identify each item by its corresponding number:

. Main Structural Components: Confirm all parts (numbers 1–13) are accounted for and ready for cabinet assembly.

Installation Tips











- . Protect the Work Area: Lay a protective mat on a flat surface to prevent scratches on components and to avoid losing small parts.
- . Step-by-Step Assembly: Assemble parts in categories to prevent confusion or incorrect installation.
- . Small Part Management: Store screws, nuts, and other small hardware in a tray or container for easy access.
- . Teamwork Recommended: Due to the weight of certain components, it is advised that at least two people collaborate to assemble the frame.
- . Safety Warning: For safe and stable installation:
 - . Properly install anti-tip devices.
 - . Distribute weight evenly.
 - . Position the cabinet against a wall.
 - . Avoid climbing or standing on the furniture.

Final Checks

- . Ensure all screws and connecting components are securely fastened.
- . Check that the frame is stable and drawers slide smoothly without obstruction.
- . Confirm that all parts have been installed as shown in the diagram.




BOX-1/2

(BJ16KE-1A1A1,BJ16KE-1A1B1)

NO.	PARTS	QTY
1		1
2		1
3		1
4		1
5		1
6		1
8		2
10		2
11		3
12		1
 Fittings Box		

BOX-2/2


(BJ16KE-1A1A2,BJ16KE-1A1B2)

NO.	PARTS	QTY
7		1
9		2
13		4


Componets List

Panels


Please ensure you have all the panels and fittings listed below before starting assembly.




1 (800*400*15mm x1)




2 (835*399*18mm x1)




3 (835*399*18mm x1)




4 (800*400*15mm x1)




5 (920*399*18mm x1)




6 (920*399*18mm x1)




7 (762*398*12mm x1)




8 (762*70*12mm x2)




9 (760*350*5mm x2)




10 (762*97*12mm x2)



11 (770*377*3mm x3)



12 (770*377*3mm x1)
















13 (823*375*4mm x4)

Component List


Fittings

Please ensure you have all the panels and fittings listed below before starting assembly.

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied are required.



A  6*30mm Wooden Dowel x 24	B  6*35mm Cam Bolt x 30	C  Cam Lock x 30
D  6*15mm Wooden Dowel x 4	E  4*40mm Screw x 4	F  4*14mm Screw x 24
G  x 32	H  x 2	I  x 1
J  x 1	K  x 2	L  2.5*12mm Screw x 2
M  x 2	N  x 8	O  x 2
P  x 4	Q  x 4	R  x 2
S  x 2	T  x 2	

Tools required



Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws






The screws length is measured from the head to the point (30mm screw shown).

Assembly Instructions

Step 1

CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




A 6x30mm



A x 4

B




B x 6


C



C x 6




Secure the bolt (B) to Part (7). Insert the wooden dowel (A) into Part (7). Attach Part (8) to Part (7). Insert the cam lock (C) and tighten securely.




Assembly Instructions

Step 2


CAM-LOCK
Tighten until shoulder is flush
with panel. Do not overtighten
or undertighten (see example below)



B



B x 12



Secure the bolt (B) to Part (5) and Part (6).

Step 3

A

6x30mm




A x 4

C





C x 6



Insert the wooden dowel (A) into Part (5).
Attach Parts (7), (8) and (10) to Part (5).
Insert the cam lock (C) and tighten
securely.


Assembly Instructions

Step 4



Carefully insert Part (11) into the grooves of Parts (5), (7) and (10). Insert the wooden dowel (A) into Parts (7) and (8).


Step 5



Attach Part (6) to Parts (7), (8) and (10). Insert the cam lock (C) and tighten securely.

Assembly Instructions

Step 6



A 6x30mm



A x 4

D 6x15mm






D x 2



Carefully insert Part (12) into the grooves of Parts (5), (6) and (10). Insert wooden dowels (A) and (D) into Parts (5) and (6).

Step 7

CAM-LOCK
Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)





B x 4



Secure the bolt (B) to Part (2) and Part (3).



Assembly Instructions

Step 8




Attach Part (10) to Part (2). Insert the cam lock (C) and tighten securely.

Step 9




Attach Part (3) to Part (10). Insert the cam lock (C) and tighten securely.



Assembly Instructions

Step 10



A 6x30mm

A x 4



D 6x15mm

D x 2

Carefully insert Part (11) into the grooves of Parts (2), (3) and (10). Insert wooden dowels (A) and (D) into Parts (2) and (3).

Step 11

CAM-LOCK
Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




Shoulder
NO GAP

B B x 4

F 4x14mm
F x 4


O O x 1




Secure the bolt (B) to Part (1). Use screws (F) to fix the magnetic catch (O) onto Part (1).

Assembly Instructions

Step 12




NOTE: If the light strip is stuck in the wrong position during application, re-sticking it will reduce its adhesiveness and may even damage the surface of the wood panel. Therefore, it is recommended that you first clean the surface of the wood panel, position the light strip correctly, then peel off the backing adhesive, and complete the proper adhesion in one go.



Assembly Instructions

Step 13

The groove is here



C



C x 4


Attach Part (1) to Parts (2) and (3).
Insert the cam lock (C) and tighten securely.



180°

After completing Step 13 , it is recommended
that two people turn the product 180 to the
next step.

Step 14



A

6x30mm




A x 4

Carefully insert Part (11) into the grooves of Parts
(2), (3) and (10). Insert the wooden dowel (A) into
Parts (2) and (3).

Assembly Instructions

Step 15




E 4x40mm

E x 4

Use screws (E) to attach Part (4) to Parts (2) and (3).

Step 16






As shown in the illustration, install the short LED light strip (J) into the LED strip channel of Part (4).



Peel of the adhesive on the back of the LED strip (J), then stick it as per diagram.

Assembly Instructions

Step 17



Step 18









Assembly Instructions

Step 19

CAM-LOCK


Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)



B x 4



F x 4




O x 1


Use screws (F) to fix the magnetic catch (O) onto Part (4). Secure the bolt (B) to Part (4).

Assembly Instructions


Step 20



Use screws to attach the hanging bracket (H) to Part (1).







Do not fully tighten wall fixing brackets until it's ready to be fixed to the wall.




Assembly Instructions

Step 21




Two people are required to attach Part (4) to Parts (5) and (6). Insert the cam lock (C) and tighten securely.



Assembly Instructions



Step 22



As shown in the illustration, remove the protective film from both sides of Parts (2), (3), (5) and (6).

Assembly Instructions



Step 23



Insert the shelf supports (N) into Parts (2), (3), (5) and (6), then place Part (9) onto them.





Assembly Instructions

Step 24



Assembly Instructions

Step 25



Assembly Instructions


Step 26

F 4x14mm






F x 16

As shown in the illustration, use screws (F) to attach Part (13) to the cabinet.



Assembly Instructions











Step 27




As shown in the illustration, pay attention to the positions of Part (O) and Part (S).

Assembly Instructions

Step 28




Install the back panel clips (G) onto the back panel. Attach the LED strip (T) in the position shown and place the LED cable (Z) in position. Plug the adaptor (I) into the connector of the LED cable (J).





Connect the light strip with the adapter, then control the light with the remote control provided.

Assembly Instructions

Step 29




Before carrying out this step, please read the “Wall Mounting and Fixing Guide” on page 6.




step 1

H




Wall

step 2




step 3

H



step 4

H



Wall



MAINTENANCE AND CARE

1. Prevent Pests

Keep wooden furniture away from damp environments to prevent pest infestations and wood deterioration. Use a dehumidifier or air conditioner during humid seasons to maintain a dry atmosphere.

2. Protect from Sunlight

Avoid placing furniture in direct sunlight to prevent cracking, discoloration, and fading. If sunlight exposure is unavoidable, use curtains or blinds to shield the furniture.

3. Keep Away from Heat Sources

Position furniture away from heaters, radiators, or open flames to avoid damage and maintain its structural integrity.

4. Routine Care

Apply furniture oil periodically to enhance the wood's shine, prevent cracking, and prolong its lifespan.

5. Regular Cleaning

Vacuum dust and debris frequently, especially beneath and around furniture, to ensure a clean and hygienic environment.

6. Maintain Dryness

Ensure adequate ventilation to prevent moisture buildup. Use a dehumidifier if necessary to protect the furniture from dampness.

7. Avoid Contact with Corrosive Substances

Keep the furniture away from acidic or alkaline substances to protect its finish and durability.

8. Gentle Cleaning

Wipe surfaces with a damp, well-wrung cloth to clean without causing water damage or swelling.

9. Minimize Sun Exposure

Prolonged exposure to sunlight can dry out and damage wood. Place furniture in shaded areas or use curtains to block harmful UV rays.

NOTE:

The battery in the remote control
requires you to purchase and install it yourself.
Model:CR2025.3.V


①



②



③



NOTE:

The remote control is supplied
without batteries Please

④



NOTE:

The correct orientation of the battery
polarity (+) and (-)

⑤




⑥



Modell : CR2025 3.V

⑦



⑧



| Cabinet

SKU:

BJ16KE-1A1A1
BJ16KE-1A1A2
BJ16KE-1A1B1
BJ16KE-1A1B2

V1.0