


Cabinet

Assembly Instruction – Please keep properly for future reference.

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.



Dimensions

Width-31.5 inch
Depth-15.7 inch
Height-36.3 inch

CONTACT US

- **Email: service@grandtunnel.com**
In order to receive assistance more quickly, please provide

THE FOLLOWING INFORMATION:

- Order number
- Purchase platform
- Purchase date
- Detailed description of the issue along with photos (if applicable)

Important – Please read these instructions carefully before starting the installation.

EN



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Please note that only the anti tip strap is provided.
You will need to provide wall plugs and screws applicable for your wall type



Safety Instructions / Warnings

Please read and follow all instructions carefully before installation and use.

- **WARNING: Risk of electric shock – Do not open or disassemble electrical parts.**
- Use only the power cord specifically provided for this product. Adaptor Input: 100-240V~, 50/60Hz, 0.5A, 30W. Output: DC 12V, 2.0A.
- Do not use with damaged power cords or plugs.
- Keep power cables away from moving or sharp parts of the furniture.
- Do not use extension cords or power strips unless specifically approved for the load.
- This product is **not a toy**. Do not allow children to play with electrical components or moving parts.
- Children under 8 years old must be kept away from the furniture unless continuously supervised.
- Keep remote controls, control switches, and ports **out of children's reach**.
- Always **disconnect the product from power** before cleaning, maintenance, or relocation.
- Do not attempt to open, modify, or repair electrical components.
- **Repairs must be performed by qualified professionals only.**
- Do not insert any foreign objects into openings or mechanisms.
- Clean with a dry cloth or a slightly damp soft cloth. Do not use solvents.
- This product is intended for **indoor use only** in dry environments.
- Do not expose the furniture to moisture, liquids, or direct sunlight.
- Ensure stability and clearance around any moving parts (e.g., lift mechanisms, recliners).
- Do not overload power outlets or USB ports beyond the specified ratings.

FCC Information

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment!

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This product may cause harmful interference.
2. This product must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this product not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

Note: This product has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This product generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the product off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the distance between the product and receiver.
- Connect the product to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for assistance.

CUSTOMER SERVICE GUIDE

Thank you for choosing our product! We are committed to providing you with excellent service. If you find any missing parts, damaged packaging, or product damage after receiving all packages, please follow the steps below to quickly contact our customer service team. We will do our best to resolve your issue.

1. Missing Parts

Verify Parts:

1. Refer to the “Parts List” in the manual to verify the name, specifications, and quantity of the missing parts.
2. Take a clear photo of the parts list and mark the missing parts with detailed information, e.g., “Missing 5 pieces of M6x30mm screws.”

Contact Us:

· By Email:

Send an email to service@grandtunnel.com, with the subject line “Missing Parts Issue.” Include the following in the email:

- A description of the missing parts and a photo of the parts list.
- Order details (order number, purchase platform, purchase date).

2. Product or Packaging Damage

If it affects normal use:

Steps:

1. Take clear photos or videos showing the damaged parts and the extent of the damage (multi-angle shots are recommended).
2. Email the photos/videos along with other details to service@grandtunnel.com, with the subject line “Product Damage Issue.”

Resolution:

After verification, we will arrange for a replacement part, product exchange, or refund as quickly as possible.

If it does not affect normal use:

Steps:

1. Contact our customer service team (by email: service@grandtunnel.com).
2. Provide a description of the damage and include relevant photos or videos.

Resolution:

We will provide repair guidance or an appropriate compensation plan based on the specific situation.

Contact Us:

- Customer Service Email: service@grandtunnel.com

Helpful Tips

To process your issue efficiently, please prepare the following information:













- Order details (order number, purchase platform, purchase date).
- Clear photos or videos.
- We are committed to providing quick and professional solutions, no matter the size of the issue, to ensure your satisfaction.

Thank you for your trust and support! We hope you enjoy using our product!

Parts List - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied are required.

A  6*30mm Wooden Dowel x 12	B  6*35mm Cam Bolt x 22	C  Cam Lock x 22
D  6*15mm Wooden Dowel x 2	E  4*40mm Screw x 4	F  4*14mm Screw x 12
G  3*12mm Screw x 8	H  x 2	I  x 2
J  x 1	K  x 1	L  x 10  3*16mm
M  x 4  2.5*12mm	N  x 2	O  x 2  4*12mm  4*40mm 
P  x 1	Q  x 1	R  x 1
S  x 2	T  x 1	U  x 4

Tools required

 Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws

mm

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170



The screws length is measured from the head to the point (30mm screw shown).


0 1 2 3

inch

Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.




Parts List - Panels


Please check you have all the panels listed below




1 (800x400x15mm x1)




2 (836x399x18mm x1)




3 (836x399x18mm x1)




4 (800x400x12mm x1)




5 (762x350x12mm x1)




6 (770x377x3mm x1)




7 (770x377x3mm x1)




8 (762x97x12mm x1)



10 (800x60x15mm x2)




11 (368x60x15mm x2)



12 (823x376x4mm x2)

Assembly Instructions




Assembly Instructions


Step 1

CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)



B x4




First, attach the cam bolt (B) to panels (2) and (3).

Step 2

Attach panel (8) to panel (2), insert the cam lock (C), and tighten it.


C x2




Rotate the frame after this step as next step

Assembly Instructions


Step 3



Attach panel (3) to panel (8),
insert the cam lock (C), and tighten it.



Step 4




First, insert the wooden dowel (A) into panels (2) and (3),
then insert panel (7) into the slots in panels (2), (3), and (8).

Assembly Instructions

Step 5

E x4




Use screw (E) to attach panel (4) to panels (2) and (3).

Assembly Instructions




Additional matching modular units are available separately and may be combined to create your desired storage configuration.


Option 1




Option 2



Option 3



Option 4




Base frame is not required for upper cabinet.

Skip Steps 6,7 and 8, proceed to Step 9.




Assemble base frame for lower cabinet installation.
Assemble in order.

Upper cabinet



Base frame

Lower cabinet





Base frame

Assembly Instructions

Step 6

CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




A x4

6x30mm

B x4

C x4

Attach the cam bolt (B) to panel (10).






First, insert the wooden dowel (A) into panel (11), then attach panel (10) to panel (11), insert the cam lock (C), and tighten it.

Assembly Instructions


Step 7

CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




B x10



First, attach the cam bolt (B) to panel (4).

Step 8



C x10



Attach panels (10) and (11) to panel (4), insert the cam lock (C), and tighten it.



Rotate the frame after this step as next step

Assembly Instructions

Step 9

A x4




6x30mm

D x2







6x15mm




First, insert wooden dowels (A) and (D) into panels (2) and (3), then insert panel (6) into the slots in panels (2), (3), and (8).

Assembly Instructions


Step 10



Peel off the adhesive backing from the LED strip (P), then attach it to the slot in panel (1) as shown in the diagram.



Cover the slot in panel (1) with the LED strip cover (N).




Use part (M) to secure the wires of the LED strip (P).

Assembly Instructions

Step 11


CAM-LOCK

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)



Shoulder
NO GAP

B x4



F x4

4x14mm





O x2



4x12mm


T x1



Attach part (O) to panel (1). Assemble the cam bolt (B) onto panel (1). Use screw (F) to attach part (T) to panel (1).

Step 12

C x4




The groove is here

Assemble panel (1) onto panels (2) and (3), insert the cam lock (C), and tighten it.


Assembly Instructions

Step 13



Thread the LED strip (P) through the holes in panel (7).

Step 14





Insert part (U) into panels (2) and (3).



Assembly Instructions

Step 15


Do not fully tighten the screws.



Following the direction shown in the figure, first secure part (M) to panel (5).



Place panel (5) with the back side facing up inside the cabinet.








Assembly Instructions

Step 16

Peel off the protective film from the adhesive backing of the LED strip (P), then adhere it to the groove on panel (5) as shown in the figure.


N x1








Cover the groove on panel (5) with the LED strip cover (N).

Assembly Instructions

Step 17







First, fold panel (5) inward by 90 degrees and carefully lift it upward. When the bottom edge passes the position of part (U), fold it inward another 90 degrees. Then lower panel (5) horizontally so that it rests precisely on top of part (U).



Assembly Instructions

Step 18





Tighten the screws fully.

Rotate part (M) 90 degrees by hand toward the LED strip (P) wires so that part (M) presses down firmly on the LED strip (P).

Assembly Instructions



Step 19



Assemble parts (H), (I), and (J) onto part (12) as shown in the figure.

Assembly Instructions

Step 20



Assemble parts (H), (I), and (K) onto part (12) as shown in the figure.


Assembly Instructions

Step 21


F x8



4x14mm






ASSEMBLY BY
2 PEOPLE











Use screw (F) to attach part (12) to panels (2) and (3).

Assembly Instructions

Step 22



Secure part (L) to the back panel. Glue part (R) to the position shown in the figure, and tuck the LED strip (P) wires into it. Connect part (Q) to the connector on the LED strip (P).





Remove the film before using the remote control.

Connect the light strip with the adapter, then control the light with the remote control provided.

Assembly Instructions




Step 23



Peel off the protective film from the surfaces of panels (2) and (3).

Assembly Instructions






Step 24



Assembly Instructions

Step 25

Use part (O) to secure the cabinet to the wall.




Please read the Guide to Wall Mounting & Fixings on the page 33 before excuting this step.

Assembly Instructions




Additional matching modular units are available separately and may be combined to create your desired storage configuration.


Option 1




Option 2



Option 3



Option 4





Step 1

If necessary, stack the cabinet on top of the cabinet shown in the figure.





ASSEMBLY BY
2 PEOPLE



Option 1





Option 2



Option 3







Option 4




Assembly Instructions

Step 2



Option 1
Option 2



Option 3



Option 4




Use screw (G) and part (S) to connect the two cabinets.



Assembly Instructions

Step 3

Connect part (Q) to the connector on the LED strip (P).



Option 4








Remove the film before using the remote control.

Connect the light strip with the adapter, then control the light with the remote control provided.

Assembly Instructions

Step 4

Use part (O) to secure the cabinet to the wall.



Please read the Guide to Wall Mounting & Fixings on the page 33 before excuting this step.

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.



Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for **supporting your unit**. **Consult a qualified tradesperson if you are unsure.**


Hints:

- 1: General rule:  always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 "Hammer Fixing" wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 "Cavity Fixing – Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 "Shield Anchor" wall plug – heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.

| Cabinet

Sku:

C001441070

C001441080

V1.0