Nightstand/End Table

Dimensions

Width - 20inch

Depth - 15.4inch

Height - 20inch

Important – Please read these instructions fully before starting assembly

⚠ Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.

• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

• Regularly check and ensure that all bolts and fittings are tightend properly.

Components - Panels

1 (38.8x 33.5x 3cm) x2

2 (38.8x 33.5x 3cm) x2

**3** (38.6 x 44.6 x 1.5cm) x2

**4** (16.8 x 45.4 x 0.27cm) x2

5 (39 x 51 x 2.4cm) x2

6 (39 x 51 x 3cm) x2

7 (11 x 35 x 1.5cm) x2

8 (11 x 35 x 1.5cm) x2

9 (11 x39.1 x 1.5cm) x2

10 (34.2 x39.9 x 0.27cm) x2

11 (15.4 x44 x 1.5cm) x2

Components - Fittings

## Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A Cam Bolt x 20	**B** Cam Lock x 20	**C** Wooden Dowel x 32
D 3.5*14mm Screw x 28	**E** 5*60mm Screw x 8	**F** 5*40mm Screw x 4
G 4*20mm Screw x 24	**H** Metal Leg x 8	**J** Handle & Fixings x 2
K Recessed Power Stripx 2	**CL** Slide Track x 2	**CR** Slide Track x 2
DL Slide Runner x 2	**DR** Slide Runner x 2	

Tools required

Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

The screws length is measured from the head to the point (30mm screw shown).

Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1

DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.

Step 2

Push the male camlock into the entry hole.

2

Step 3

Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3

Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.

4

Assembly Instructions

Assembly Instructions

Step 1

D x 12

CL x 2

CR x 2

CL + CR + DL + DR

Use screw (D) to secure slide track (CL) to part (1) with a screwdriver.
Use screw (D) to secure slide track (CR) to part (2) with a screwdriver.

× 2

Step 2

A x 8

CAM-LOCK
Tighten until shoulder is flush
with panel.Do not overtighten
or undertighten(see example below)

Shoulder

NO GAP

Panel

Panel

Attach cam bolt (A) to part (1, 2) with a screwdriver.

× 2

Assembly Instructions

Step 3

C x 8

× 2

Insert wooden dowel (C) into part (3).

Step 4

B x 8

× 2

Attach part (1, 2) to part (3), then insert and secure cam lock (B) to part (3) to lock them.

Assembly Instructions

Step 5

× 2

Insert wooden dowel (C) into part (1,2).
Slide part (4) into grooves as per diagram.

Step 6

× 2

Attach part (5) to part (1, 2) using screw (E) with a screwdriver.

Assembly Instructions

G x 24

H x 8

H

G

G

H

H

G

5

G

G

H

1

× 2

Use screw (G) to secure metal leg (H) to part (5) with a screwdriver.

C x 8

C

C

C

C

2

1

× 2

Insert wooden dowel (C) into part (1, 2).

Assembly Instructions

CAM-LOCK
Tighten until shoulder is flush
with panel.Do not overtighten
or undertighten(see example below)

Shoulder

NO GAP

Panel

Panel

A

A

A

A

A

6

A x 8

× 2

Attach cam bolt (A) to part (6) with a screwdriver.

6

B

B

B

B

2

1

B x 8

× 2

1	2	3

Attach part (6) to part (1, 2), then insert and secure cam lock (B) to part (1, 2) to lock them.

Assembly Instructions

Step 11

C x 4

F x 4

9

7

× 2

8

9

10

8

Insert wooden dowel (C) into part (9), then attach part (7, 8) to part (9) using screw (F) with a screwdriver.
Slide part (10) into grooves as per diagram.

Step 12

A x 4

C x 4

J x 2

CAM-LOCK
Tighten until shoulder is flush with panel.Do not overtighten or undertighten(see example below)

Shoulder

NO GAP

Panel

Panel

Step 13-1

Step 13-2

A

11

A

J

C

11

C

× 2

Attach cam bolt (A) and handle (J) to part (11) with a screwdriver.
Insert wooden dowel (C) into part (11).

11

Assembly Instructions

Step 13

B

10

8

B

11

× 2

1	2	3

Attach part (11) to part (7, 8), then insert and secure cam lock (B) to part (7, 8) to lock it.

Step 14

D
D x 12

DL
DL x 2

DR
DR x 2

D   D

D

DL

D

D   D

DR

D   D

D

11

× 2

Use screw (D) to secure slide runner (DL, DR) to part (7, 8) with a screwdriver.

12

Assembly Instructions

× 2

To insert the assembled drawers inside the unit, slightly tip the end of the drawer down and drop the rollers of the drawer slide runners behind the rollers of slide tracks on the unit. Then slide the drawers into the unit.

Assembly Instructions

Step 16

D x 4

K x 2

6

× 2

Attach recessed power strip (K) to top panel (6) using screw (D) with a screwdriver.

Step 17

Assembly is complete.